



Bartels Rotation 2242 – Daily Averages  
Leakage Current – M1A – Ground Side  
(07-Oct-1997 thru 02-Nov-1997) (280/1997 thru 306/1997)




11 16 21 26 Nov 1  
time (07-Oct-1997 to 03-Nov-1997)

Bartels Rotation 2242 – Daily Averages  
 Leakage Current – M1A – High Voltage Side  
 (07-Oct-1997 thru 02-Nov-1997) (280/1997 thru 306/1997)




time (07-Oct-1997 to 03-Nov-1997)

Bartels Rotation 2242 – Daily Averages  
 Leakage Current – M2A – Ground Side  
 (07-Oct-1997 thru 02-Nov-1997) (280/1997 thru 306/1997)



11 16 21 26 Nov 1  
 time (07-Oct-1997 to 03-Nov-1997)


Bartels Rotation 2242 – Daily Averages  
 Leakage Current – M2A – High Voltage Side  
 (07-Oct-1997 thru 02-Nov-1997) (280/1997 thru 306/1997)



11                      16                      21                      26                      Nov 1


time (07-Oct-1997 to 03-Nov-1997)

Bartels Rotation 2242 – Daily Averages  
 Leakage Current – M1B – Ground Side  
 (07-Oct-1997 thru 02-Nov-1997) (280/1997 thru 306/1997)




time (07-Oct-1997 to 03-Nov-1997)

Bartels Rotation 2242 – Daily Averages  
 Leakage Current – M1B – High Voltage Side  
 (07-Oct-1997 thru 02-Nov-1997) (280/1997 thru 306/1997)




11                      16                      21                      26                      Nov 1  
 time (07-Oct-1997 to 03-Nov-1997)

Bartels Rotation 2242 – Daily Averages  
Leakage Current – M2B – Ground Side  
(07-Oct-1997 thru 02-Nov-1997) (280/1997 thru 306/1997)



11 16 21 26 Nov 1  
time (07-Oct-1997 to 03-Nov-1997)

Bartels Rotation 2242 – Daily Averages  
 Leakage Current – M2B – High Voltage Side  
 (07-Oct-1997 thru 02-Nov-1997) (280/1997 thru 306/1997)



11                      16                      21                      26                      Nov 1

time (07-Oct-1997 to 03-Nov-1997)