



Bartels Rotation 2247 – Daily Averages
Leakage Current – M1A – Ground Side
(19-Feb-1998 thru 17-Mar-1998) (050/1998 thru 076/1998)




21 26 Mar 1 6 11 16
time (19-Feb-1998 to 18-Mar-1998)

Bartels Rotation 2247 – Daily Averages
Leakage Current – M1A – High Voltage Side
(19-Feb-1998 thru 17-Mar-1998) (050/1998 thru 076/1998)




21 26 Mar 1 6 11 16
time (19-Feb-1998 to 18-Mar-1998)

Bartels Rotation 2247 – Daily Averages
Leakage Current – M2A – Ground Side
(19-Feb-1998 thru 17-Mar-1998) (050/1998 thru 076/1998)




Bartels Rotation 2247 – Daily Averages
Leakage Current – M2A – High Voltage Side
(19-Feb-1998 thru 17-Mar-1998) (050/1998 thru 076/1998)




21 26 Mar 1 6 11 16
time (19-Feb-1998 to 18-Mar-1998)

Bartels Rotation 2247 – Daily Averages
Leakage Current – M1B – Ground Side
(19-Feb-1998 thru 17-Mar-1998) (050/1998 thru 076/1998)



21 26 Mar 1 6 11 16
time (19-Feb-1998 to 18-Mar-1998)


Bartels Rotation 2247 – Daily Averages
Leakage Current – M1B – High Voltage Side
(19-Feb-1998 thru 17-Mar-1998) (050/1998 thru 076/1998)




21 26 Mar 1 6 11 16

time (19-Feb-1998 to 18-Mar-1998)

Bartels Rotation 2247 – Daily Averages
Leakage Current – M2B – Ground Side
(19-Feb-1998 thru 17-Mar-1998) (050/1998 thru 076/1998)



Bartels Rotation 2247 – Daily Averages
Leakage Current – M2B – High Voltage Side
(19-Feb-1998 thru 17-Mar-1998) (050/1998 thru 076/1998)



21 26 Mar 1 6 11 16

time (19-Feb-1998 to 18-Mar-1998)