




Bartels Rotation 2260 – Daily Averages  
Leakage Current – M1A – Ground Side  
(05-Feb-1999 thru 03-Mar-1999) (036/1999 thru 062/1999)




Bartels Rotation 2260 – Daily Averages  
 Leakage Current – M1A – High Voltage Side  
 (05-Feb-1999 thru 03-Mar-1999) (036/1999 thru 062/1999)



Bartels Rotation 2260 – Daily Averages  
Leakage Current – M2A – Ground Side  
(05-Feb-1999 thru 03-Mar-1999) (036/1999 thru 062/1999)




Bartels Rotation 2260 – Daily Averages  
Leakage Current – M2A – High Voltage Side  
(05-Feb-1999 thru 03-Mar-1999) (036/1999 thru 062/1999)




6 11 16 21 26 Mar 1  
time (05-Feb-1999 to 04-Mar-1999)

Bartels Rotation 2260 – Daily Averages  
Leakage Current – M1B – Ground Side  
(05-Feb-1999 thru 03-Mar-1999) (036/1999 thru 062/1999)




6 11 16 21 26 Mar 1  
time (05-Feb-1999 to 04-Mar-1999)

Bartels Rotation 2260 – Daily Averages  
 Leakage Current – M1B – High Voltage Side  
 (05-Feb-1999 thru 03-Mar-1999) (036/1999 thru 062/1999)



Bartels Rotation 2260 – Daily Averages  
 Leakage Current – M2B – Ground Side  
 (05-Feb-1999 thru 03-Mar-1999) (036/1999 thru 062/1999)



Bartels Rotation 2260 – Daily Averages  
Leakage Current – M2B – High Voltage Side  
(05-Feb-1999 thru 03-Mar-1999) (036/1999 thru 062/1999)

