



Bartels Rotation 2313-2326 - Daily Averages
Leakage Current - M1A - Ground Side
(06-Jan-2003 thru 18-Jan-2004) (006/2003 thru 018/2004)




Apr Jul Oct Jan
time (06-Jan-2003 to 19-Jan-2004)

Bartels Rotation 2313-2326 – Daily Averages
Leakage Current – M1A – High Voltage Side
(06-Jan-2003 thru 18-Jan-2004) (006/2003 thru 018/2004)




Apr Jul Oct Jan
time (06-Jan-2003 to 19-Jan-2004)

Bartels Rotation 2313-2326 - Daily Averages
Leakage Current - M2A - Ground Side
(06-Jan-2003 thru 18-Jan-2004) (006/2003 thru 018/2004)




Apr Jul Oct Jan
time (06-Jan-2003 to 19-Jan-2004)

Bartels Rotation 2313-2326 - Daily Averages
Leakage Current - M2A - High Voltage Side
(06-Jan-2003 thru 18-Jan-2004) (006/2003 thru 018/2004)




Apr Jul Oct Jan
time (06-Jan-2003 to 19-Jan-2004)

Bartels Rotation 2313-2326 – Daily Averages
Leakage Current – M1B – Ground Side
(06-Jan-2003 thru 18-Jan-2004) (006/2003 thru 018/2004)




Apr Jul Oct Jan
time (06-Jan-2003 to 19-Jan-2004)

Bartels Rotation 2313-2326 - Daily Averages
Leakage Current - M1B - High Voltage Side
(06-Jan-2003 thru 18-Jan-2004) (006/2003 thru 018/2004)




Apr Jul Oct Jan
time (06-Jan-2003 to 19-Jan-2004)

Bartels Rotation 2313–2326 – Daily Averages
 Leakage Current – M2B – Ground Side
 (06-Jan-2003 thru 18-Jan-2004) (006/2003 thru 018/2004)



Apr Jul Oct Jan
 time (06-Jan-2003 to 19-Jan-2004)

Bartels Rotation 2313-2326 - Daily Averages
Leakage Current - M2B - High Voltage Side
(06-Jan-2003 thru 18-Jan-2004) (006/2003 thru 018/2004)



Apr Jul Oct Jan
time (06-Jan-2003 to 19-Jan-2004)