



Bartels Rotation 2316-2329 - Daily Averages
Leakage Current - M1A - Ground Side
(28-Mar-2003 thru 08-Apr-2004) (087/2003 thru 099/2004)




Apr Jul Oct Jan Apr
time (28-Mar-2003 to 09-Apr-2004)

Bartels Rotation 2316-2329 - Daily Averages
Leakage Current - M1A - High Voltage Side
(28-Mar-2003 thru 08-Apr-2004) (087/2003 thru 099/2004)




Apr Jul Oct Jan Apr
time (28-Mar-2003 to 09-Apr-2004)

Bartels Rotation 2316-2329 – Daily Averages
Leakage Current – M2A – Ground Side
(28-Mar-2003 thru 08-Apr-2004) (087/2003 thru 099/2004)




Apr Jul Oct Jan Apr
time (28-Mar-2003 to 09-Apr-2004)

Bartels Rotation 2316-2329 - Daily Averages
Leakage Current - M2A - High Voltage Side
(28-Mar-2003 thru 08-Apr-2004) (087/2003 thru 099/2004)




Apr Jul Oct Jan Apr
time (28-Mar-2003 to 09-Apr-2004)

Bartels Rotation 2316-2329 - Daily Averages
Leakage Current - M1B - Ground Side
(28-Mar-2003 thru 08-Apr-2004) (087/2003 thru 099/2004)




Apr Jul Oct Jan Apr
time (28-Mar-2003 to 09-Apr-2004)

Bartels Rotation 2316-2329 - Daily Averages
Leakage Current - M1B - High Voltage Side
(28-Mar-2003 thru 08-Apr-2004) (087/2003 thru 099/2004)




Apr Jul Oct Jan Apr
time (28-Mar-2003 to 09-Apr-2004)

Bartels Rotation 2316-2329 - Daily Averages
Leakage Current - M2B - Ground Side
(28-Mar-2003 thru 08-Apr-2004) (087/2003 thru 099/2004)



Apr Jul Oct Jan Apr
time (28-Mar-2003 to 09-Apr-2004)

Bartels Rotation 2316-2329 - Daily Averages
Leakage Current - M2B - High Voltage Side
(28-Mar-2003 thru 08-Apr-2004) (087/2003 thru 099/2004)



Apr Jul Oct Jan Apr
time (28-Mar-2003 to 09-Apr-2004)