



Bartels Rotation 2331 – Daily Averages  
Leakage Current – M1A – Ground Side  
(06-May-2004 thru 01-Jun-2004) (127/2004 thru 153/2004)




6 11 16 21 26 Jun 1  
time (06-May-2004 to 02-Jun-2004)

Bartels Rotation 2331 – Daily Averages  
Leakage Current – M1A – High Voltage Side  
(06-May-2004 thru 01-Jun-2004) (127/2004 thru 153/2004)




6 11 16 21 26 Jun 1  
time (06-May-2004 to 02-Jun-2004)

Bartels Rotation 2331 – Daily Averages  
Leakage Current – M2A – Ground Side  
(06-May-2004 thru 01-Jun-2004) (127/2004 thru 153/2004)




Bartels Rotation 2331 – Daily Averages  
Leakage Current – M2A – High Voltage Side  
(06-May-2004 thru 01-Jun-2004) (127/2004 thru 153/2004)




6 11 16 21 26 Jun 1  
time (06-May-2004 to 02-Jun-2004)

Bartels Rotation 2331 – Daily Averages  
Leakage Current – M1B – Ground Side  
(06-May-2004 thru 01-Jun-2004) (127/2004 thru 153/2004)




Bartels Rotation 2331 – Daily Averages  
Leakage Current – M1B – High Voltage Side  
(06-May-2004 thru 01-Jun-2004) (127/2004 thru 153/2004)




6 11 16 21 26 Jun 1  
time (06-May-2004 to 02-Jun-2004)

Bartels Rotation 2331 – Daily Averages  
Leakage Current – M2B – Ground Side  
(06-May-2004 thru 01-Jun-2004) (127/2004 thru 153/2004)



6 11 16 21 26 Jun 1  
time (06-May-2004 to 02-Jun-2004)

Bartels Rotation 2331 – Daily Averages  
Leakage Current – M2B – High Voltage Side  
(06-May-2004 thru 01-Jun-2004) (127/2004 thru 153/2004)



6 11 16 21 26 Jun 1  
time (06-May-2004 to 02-Jun-2004)