



Bartels Rotation 2331 – Daily Averages
Leakage Current – M1A – Ground Side
(06-May-2004 thru 01-Jun-2004) (127/2004 thru 153/2004)




6 11 16 21 26 Jun 1
time (06-May-2004 to 02-Jun-2004)

Bartels Rotation 2331 – Daily Averages
 Leakage Current – M1A – High Voltage Side
 (06-May-2004 thru 01-Jun-2004) (127/2004 thru 153/2004)




6 11 16 21 26 Jun 1
 time (06-May-2004 to 02-Jun-2004)

Bartels Rotation 2331 – Daily Averages
 Leakage Current – M2A – Ground Side
 (06–May–2004 thru 01–Jun–2004) (127/2004 thru 153/2004)




Bartels Rotation 2331 – Daily Averages
 Leakage Current – M2A – High Voltage Side
 (06-May-2004 thru 01-Jun-2004) (127/2004 thru 153/2004)




6 11 16 21 26 Jun 1
 time (06-May-2004 to 02-Jun-2004)

Bartels Rotation 2331 – Daily Averages
 Leakage Current – M1B – Ground Side
 (06-May-2004 thru 01-Jun-2004) (127/2004 thru 153/2004)




6 11 16 21 26 Jun 1
 time (06-May-2004 to 02-Jun-2004)

Bartels Rotation 2331 – Daily Averages
 Leakage Current – M1B – High Voltage Side
 (06-May-2004 thru 01-Jun-2004) (127/2004 thru 153/2004)



6 11 16 21 26 Jun 1
 time (06-May-2004 to 02-Jun-2004)


Bartels Rotation 2331 – Daily Averages
 Leakage Current – M2B – Ground Side
 (06-May-2004 thru 01-Jun-2004) (127/2004 thru 153/2004)



6 11 16 21 26 Jun 1

time (06-May-2004 to 02-Jun-2004)

Bartels Rotation 2331 – Daily Averages
 Leakage Current – M2B – High Voltage Side
 (06-May-2004 thru 01-Jun-2004) (127/2004 thru 153/2004)



6 11 16 21 26 Jun 1
 time (06-May-2004 to 02-Jun-2004)