



Bartels Rotation 2392 – Daily Averages
Leakage Current – M1A – Ground Side
(08–Nov–2008 thru 04–Dec–2008) (313/2008 thru 339/2008)




11 16 21 26 Dec 1
time (08–Nov–2008 to 05–Dec–2008)

Bartels Rotation 2392 – Daily Averages
Leakage Current – M1A – High Voltage Side
(08–Nov–2008 thru 04–Dec–2008) (313/2008 thru 339/2008)




Bartels Rotation 2392 – Daily Averages
Leakage Current – M2A – Ground Side
(08–Nov–2008 thru 04–Dec–2008) (313/2008 thru 339/2008)




11 16 21 26 Dec 1
time (08–Nov–2008 to 05–Dec–2008)

Bartels Rotation 2392 – Daily Averages
Leakage Current – M2A – High Voltage Side
(08–Nov–2008 thru 04–Dec–2008) (313/2008 thru 339/2008)




11 16 21 26 Dec 1
time (08–Nov–2008 to 05–Dec–2008)


Bartels Rotation 2392 – Daily Averages
Leakage Current – M1B – Ground Side
(08–Nov–2008 thru 04–Dec–2008) (313/2008 thru 339/2008)



Bartels Rotation 2392 – Daily Averages
Leakage Current – M1B – High Voltage Side
(08–Nov–2008 thru 04–Dec–2008) (313/2008 thru 339/2008)




Bartels Rotation 2392 – Daily Averages
Leakage Current – M2B – Ground Side
(08–Nov–2008 thru 04–Dec–2008) (313/2008 thru 339/2008)



11 16 21 26 Dec 1
time (08–Nov–2008 to 05–Dec–2008)

Bartels Rotation 2392 – Daily Averages
Leakage Current – M2B – High Voltage Side
(08–Nov–2008 thru 04–Dec–2008) (313/2008 thru 339/2008)



11 16 21 26 Dec 1
time (08–Nov–2008 to 05–Dec–2008)