Bartels Rotation 2396 – Daily Averages
Leakage Current – M1A – Ground Side
(24–Feb–2009 thru 22–Mar–2009) (055/2009 thru 081/2009)



Bartels Rotation 2396 – Daily Averages
Leakage Current – M1A – High Voltage Side
(24–Feb–2009 thru 22–Mar–2009) (055/2009 thru 081/2009)



Bartels Rotation 2396 – Daily Averages
Leakage Current – M2A – Ground Side
(24–Feb–2009 thru 22–Mar–2009) (055/2009 thru 081/2009)



Bartels Rotation 2396 – Daily Averages
Leakage Current – M2A – High Voltage Side
(24–Feb–2009 thru 22–Mar–2009) (055/2009 thru 081/2009)



Bartels Rotation 2396 – Daily Averages
Leakage Current – M1B – Ground Side
(24–Feb–2009 thru 22–Mar–2009) (055/2009 thru 081/2009)



Bartels Rotation 2396 – Daily Averages
Leakage Current – M1B – High Voltage Side
(24–Feb–2009 thru 22–Mar–2009) (055/2009 thru 081/2009)



Bartels Rotation 2396 – Daily Averages
Leakage Current – M2B – Ground Side
(24–Feb–2009 thru 22–Mar–2009) (055/2009 thru 081/2009)



Bartels Rotation 2396 – Daily Averages
Leakage Current – M2B – High Voltage Side
(24–Feb–2009 thru 22–Mar–2009) (055/2009 thru 081/2009)